

Multi-Mic+ LED indicator patterns

Status	LED information	Description
Powered Off	No LED	No LED pattern when MM+ is Off
Turning power ON		Green LED for 3 seconds (Once)
Turning power OFF		Short 3 white LED flashes (Once)
Power On		Short green LED flash every 2 seconds
Volume control disabled		Short green, white LED flashes every 2 seconds
Low battery		Short 3 green LED flashes every 2 seconds
Volume control disabled + Low battery		Short green, white, green LED flashes every 2 seconds
Volume control activated / Volume control turned deactivated		Long green, blue, green LED flash when activated or deactivated (Once)
Test mode		Constant White LED
Pairing mode		Short blue LED flash every second
Pairing succesfull		Blue LED for 3 seconds
Volume changes		Short white LED flash (Once when pressing Volume up or down)
Volume limit reached		White LED for 2 seconds
Mode selection		Green LED for 2 seconds (Mode LED)
Firmware update ongoing		Short blue, white, green LED flashes
Firmware update successful		Green LED flash for 1 second
Boot error (Service needed)		Short blue, white, green flashes every 2 seconds
Connection lost		Short 3 white LED flashes every 2 seconds
Factory reset		Short 2 green LED flashes

Battery charging status

- 100% : 4 **green** static LEDs
- 99-75%: 4 **green** LEDs (Top one pulsing)
- 74-50%: 3 **green** LEDs (Top one pulsing)
- 49-25%: 2 **green** LEDs (Top one pulsing)
- <25%: 1 **green** pulsing LED



100%	99-75%	74-50%	49-25%	<25%
				
				
				
				

Battery level status

Press & hold the mode button for >1 second

- >75%: 4 **green** LEDs shown
- 50%-74%: 3 **green** LEDs shown
- 25%-49%: 2 **green** LEDs shown
- <25%: 1 **green** LED shown

Stops when button is released.



>75%	74-50%	49-25%	<25%
			
			
			
			